


CONNECTOR GAGES



CONNECTOR GAGE COMPANY
AIRPORT BUSINESS PARK
2449 S. E. DIXIE HIGHWAY
STUART FL. 33494
(305) 288-1414

CONNECTOR INTERFACE GAGES

• FAST •
• ACCURATE •
• EASY TO USE •


DESCRIPTION

Connector Interface Gages measure the critical linear interface dimensions of R.F. Connectors. These dimensions must be maintained in order to provide proper electrical performance and mechanical mating of male and female connectors.

Each Gage Head Assembly consists of a precision dial indicator with special Gage Heads and Plungers designed to mate with the specific connector to be tested. Each measurement reflects the actual deviation from Zero, which corresponds to a direct measurement of the interface dimension from the Connector Reference Plane.

These Gage Head Assemblies are available in Precision Connector Gage Kits. All gage parts are manufactured in the U.S.A. and are made of special stainless steel heat treated to provide long-wearing characteristics along with excellent dimensional stability.

Refer to the Gage Kit Selection Table for Model No.'s that are available. Refer to the specific Connector Series and Gage Head Model No. for the actual interface dimension to be measured.



PRECISION CONNECTOR GAGE KITS

CONNECTOR INTERFACE GAGES

• **FAST** •
• **ACCURATE** •
• **EASY TO USE** •

GAGE KIT SELECTION

SERIES	MODEL NO.	GAGE HEAD ASSEMBLIES
2.4mm	2.4mm-4MF-STP	2.4mm-FP, 2.4mm-MP, 2.4mm-TFP, 2.4mm-TMP
	2.4mm-2MF-SP	2.4mm-FP, 2.4mm-MP
	2.4mm-2MF-TP	2.4mm-TFP, 2.4mm-TMP
3.5mm	3.5mm-4MF-STP	3.5mm-FP, 3.5mm-MP, 3.5mm-TFP, 3.5mm-TMP
	3.5mm-2MF-SP	3.5mm-FP, 3.5mm-MP
	3.5mm-2MF-TP	3.5mm-TFP, 3.5mm-TMP
SSMA	SSMA-5MF-SPD	SSMA-FP, SSMA-MP, SSMA-FD, SSMA-MD, SSMA-MPL
	SSMA-4MF-SPD	SSMA-FP, SSMA-MP, SSMA-FD, SSMA-MD
	SSMA-4MF-TPD	SSMA-TFP, SSMA-TMP, SSMA-TFD, SSMA-TMD
SMA	SMA-5MF-SPD	SMA-FP, SMA-MP, SMA-FD, SMA-MD, SMA-MPL
	SMA-4MF-SPD	SMA-FP, SMA-MP, SMA-FD, SMA-MD
	SMA-4MF-TPD	SMA-TFP, SMA-TMP, SMA-TFD, SMA-TMD
	SMA-3MF-SP	SMA-FP, SMA-MP, SMA-MPL
	SMA-4MF-STP	SMA-FP, SMA-MP, SMA-TFP, SMA-TMP
SMB	SMB-5MF-SPD	SMB-MP, SMB-FP, SMB-MD, SMB-FD, SMB-MPL
	SMB-4MF-SPD	SMB-MP, SMB-FP, SMB-MD, SMB-FD
SMC	SMC-4MF-SPD	SMC-MP, SMC-FP, SMC-MD, SMC-FD
TNC	TNC-4MF-SPD	TNC-FP, TNC-MP, TNC-FD, TNC-MD
	TNC-4MF-TPD	TNC-TFP, TNC-TMP, TNC-TFD, TNC-TMD
	TNC-4MF-STP	TNC-FP, TNC-MP, TNC-TFP, TNC-TMP
TK	TK-4MF-SPD	TK-FP, TK-MP, TK-FD, TK-MD
	TK-4MF-TPD	TK-TFP, TK-TMP, TK-TFD, TK-TMD
SC	SC-4MF-SPD	SC-FP, SC-MP, SC-FD, SC-MD
	SC-4MF-TPD	SC-TFP, SC-TMP, SC-TFD, SC-TMD
N	N-2MF-SP	N-FP, N-MP
	N-2MF-TP	N-TFP, N-TMP
	N-4MF-STP	N-FP, N-MP, N-TFP, N-TMP
HN	HN-4MF-SPD	HN-FP, HN-MP, HN-FD, HN-MD
TRT	TRT-4MF-SP	TRT-FP1, TRT-FP2, TRT-MP1, TRT-MP2
TWTNC	TWTNC-4MF-SP	TWTNC-FFP, TWTNC-FMP, TWTNC-MFP, TWTNC-MMP
APC7	APC7-1H-P	APC7-P
GR900	GR900-1H-P	GR900-P